



Inspiring innovation.



# SOLUTIONS FOR TRIALS

## Tannin Solutions

- ☪ Add 1g EnartisTan tannin to 100mL of a 13% alcohol solution using a neutral spirit and distilled water.
- ☪ Mix well.

1mL of tannin solution in 100 mL of wine corresponds to 10g of EnartisTan tannin per 100L (0.8lb/1000gal).

## Polysaccharide Solutions

- ☪ Rehydrate 1g Enartis Polysaccharide from the Surli Range in 50mL of 100°F water for 2 hours. Add Polysaccharide solution to 13mL of 95% ethanol and 37mL of water.
- ☪ Let cool to room temperature with periodic mixing.
- ☪ The solution must be kept at 68°F and mixed two or three time daily for three days.
- ☪ After three days, the solution can be used for trials.

1mL of polysaccharide solution in 100 mL of wine corresponds to 10g of Enartis Polysaccharide from the Surli Range per 100L (.85lb/1000gal)

*Note:* Surli Elevage, Surli Velvet and Surli Vitis can be dissolved in a 13% ethanol solution and used immediately.